4424 DIGITAL LUGGAGE SCALE

INSTRUCTIONS MANUAL

This digital luggage scale has the following characteristics: precision weighing, attractive design, easy to carry, durability and much more. It is perfect for travelling, family use, shopping, or outdoor activities. Please read this manual carefully to ensure correct operation of the scale.

ITEM SPECIFICATIONS

Equipped with High Precision Strain Gauge Sensor System.
Maximum Capacity: 40 kg.
Minimum Capacity: 0,5kg.
Unit: kg/lb.
One-Button function.
Power: 1 Lithium Battery (CR2032) included.

SCALE OPERATION

Prior to first use, remove the battery stopper film. Press the *POWER* button to turn on scale. The LCD displays *888* at startup. After startup, be sure to hold the scale in a vertical state until it emits a Beep tone (within 3seconds) and the LCD display reads *0.0 kg*.

The object to be weighed should be attached to the scale while the LCD displays *0.0 kg*. Next grip the scale handle and lift up the article. The scale will emit a Beep tone when it has weighed the article. The LCD will display the article weight along with *Hold* message in the lower right corner of the LCD screen.

To reset the scale and weigh another article, remove article from scale, then press and release *POWER* button. Scale will then emit Beep and LCD will display *0.0 kg*.

Press *POWER* button to turn scale off (scale will power off automatically after 60 seconds of no usage).

UNIT TRANSITION (KG/LB)

Press *POWER* button to turn on scale. Press *POWER* button again and the LCD display will show the message *lb.* Press *POWER* button again to weigh in kg.

TARE FUNCTION

When you use a container to weigh an article, weigh the container by itself first. After unit emits Beep and LCD displays container weight with *Hold* message in lower right corner, continue to lift container, press and release *POWER* button to reset scale to *0.0 kg*.

Place the article to be weighed in the container. Now only the object weight will be displayed.

USAGE NOTES

- The maximum weight limit for this scale is 40kg. If objects heavier than 40kg are placed on the scale, the display will show *ERR* message. Attempting to weigh items over 40kg could damage the scale.
- When the LCD displays the *Battery Symbol*, it means the battery is low. Please change the battery as soon as possible.
- To ensure the highest accuracy possible, avoid shaking or rocking while weighing items in the scale.

CLEANING AND MAINTENANCE

- Wipe the scale with a slightly damp cloth. DO NOT immerse the scale in water nor use chemical-abrasive cleaning agents on the scale surface.
- DO NOT stress the triangle ring for long time. While travelling, keep the scale away from objects with sharp ends (such as toys or stationery) to avoid turning on causing accidental battery consumption.
- To ensure accuracy, DO NOT use this scale near strong magnetic fields.
- Keep the scale away from children to avoid danger of swallowing batteries or small components.