

## Multifunction Alarm Clock User manual (Eng)



It is recommended to read this user manual carefully and keep it for future reference.

### Product overview:



### Specificacions:

- Charging voltaje: 5V  $\equiv$  2A
- Wireless charging: 5V  $\equiv$  1A, 5W
- Working distance up to 6mm
- Suitable for all mobile devices with Qi technology.
- Temperature range: 0-50°C, 32-122°F
- Clock: (12/24h)

### Operation:

Connect the device to the power supply.

### Wireless charger operation:

Place your Qi compatible device on top of the wireless charger, make sure that it is face up and centered.

Note: To ensure that the charger works correctly, it is recommended to remove the protective case of your phone.

### Clock operation:

Press the SET button to switch between DP1 and DP2 modes:

- DP1 Mode: The screen will show time, date and temperature.
- DP2 Mode: The screen will show only time and temperature.

Long press the UP button to switch the temperature format between °C y °F.

- HOUR FORMAT: Hold down the SET button for 3 seconds, until the display shows 12H/24H. Press UP or DOWN to change it and SET to fix it. Press UP or DOWN to change the hour.

When you are using the 12 hours format, a white dot will be displayed at the top left side of the screen when the time is after the midday.

Press SET button to show the date. Long press SET again to adjust the below details:

- YEAR
- DATE
- ALARMS A1, A2 Y A3. Press UP/DOWN buttons to enable the alarm (The display will show ON near to the alarm name when it is enabled). Long press SET to adjust the alarm. Press SET to change to the next alarm.

- To adjust the brightness: Press DOWN button to adjusts the brightness.

-BA: The brightness will adjust automatically depending on the time.

-B1-B4: Adjust the brightness from lower to higher.

-L5: The screen will turn off automatically. Press DOWN to turn on the screen.

### Warnings:

1. Do not expose this product to rain or damp conditions.
2. Prevent this item from falling as it could cause serious damage.
3. Do not dismantle, repair or modify this product by yourself, contact an authorized specialist.
4. In order to avoid any risk, do not dispose of this product inappropriately.
5. Clean it with a dry cloth.
6. Do not place this item near sources of heat or expose to direct sunlight.
7. Do not insert any metal objects into this device as there is a risk of causing a short circuit in the unit.
8. To avoid risk, do not place any metal objects between the charger and the mobile device during the charging process.
9. Do not use mobile devices with a metal case.



This symbol both in the product and its user manual indicates that at the end of the devices electrical life, it should be recycled separately from your household waste. There are adequate means to dispose of this material for proper recycling. For more information, contact your local authorities.