

391398 User Manual



To change the battery, unscrew and remove the tray. The positive pole must be placed downwards. Once placed, insert the tray again and screw again.

Warnings:

- Small parts
- Non-rechargeable batteries are not to be recharged. Exhausted batteries are to be removed from the toy.
- Contains coin battery. Hazardous if swallowed.
- This product contains a coin battery. A coin battery can cause serious internal chemical burns if swallowed.
- Dispose of used batteries immediately. Keep new and used batteries away from children. If you think batteries might have been swallowed or placed inside any part of the body, seek immediate medical attention.
- The supply terminals are not to be short-circuited.
- Batteries are to be inserted with the correct polarity (+ and -).



CE
MADE IN PRC



This symbol both in the product and its user manual indicates that at the end of the device's electrical life, it should be recycled separately from your household waste. There are adequate means to dispose of this material for proper recycling. For more information, contact your local authorities.
Before disposing of the WEEE, please remove the batteries.