

391472

User Manual (Eng)



It is recommended to read this user manual carefully and keep it for future reference



SPECIFICATIONS:

Capacity: 5000mAh / 3.7V – Lithium Polymer Battery.
Type-C Input/Output: 5V \equiv 2.4A
2 USB Outputs : 5V \equiv 2.4A, 12W
Battery Life: More than 500 charging cycles.
With charge indicator, 4 Leds.
With solar charge indicator, 1 Led.
ON/OFF button.



INSTRUCTIONS:

Indicator light: During the charging process of the power bank the blue lights of the charge indicator will start to flash. As the charging process is completing the lights will start to stay on.

When a mobile device is connected to the power bank the indicator lights will appear, according to the charge level available on the unit. During the charge transmission, the power of the portable charging device will decrease and the lights on the charge indicator will start to disappear indicating the remaining charge capacity available. Every light represents 25% of the total charge.

Charging the portable power device:

Wire charging: Connect a cable to the power bank Type-C port and connect the other end to a suitable power supply.

Solar Charging: Expose the solar pannel of the power bank to the direct sunlight. When it is charging correctly the green light indicator will turn on.

Note: Solar charging is a slow process and its performance depends of the enviromental factors.

Charging mobile devices:

Connect the USB cable to the mobile device and connect the other end of the USB cable to the out port of the portable charger.

Remove the USB cable at the end of each process.

IMPORTANT SAFETY PRECAUTIONS:

Before use please note the following safety precautions. Failure to comply may be dangerous and cause damage to your mobile electronic devices.

- The power bank unit contains an internal 5.000mAh lithium polymer battery. Upon initial use or after a prolonged period of storage, fully charge the unit before use. The unit will reach its maximum performance after 2 or 3 full charging and discharging cycles.
- Using an incorrect power adaptor or USB cable could cause damage to both your mobile devices and the Power Bank.
- Do not submerge in water or expose to adverse weather conditions
- Avoid dropping the device.
- Keep the device away from fire and high temperatures.
- Keep the device out of reach of children.
- During charging, the Power Bank case may become slightly warm. This is normal as the charging and discharging process generates heat.
- To avoid risk, do not place any metal objects between the charger and the mobile device during the charging process.



This symbol both in the product and its user manual indicates that at the end of the devices electrical life, it should be recycled separately from your household waste. There are adequate means to dispose of this material for proper recycling. For more information, contact your local authorities.



Hereby, Miko Catal Importaciones S.L. declares that this radio equipment is in compliance with Directive 2014/53/EU. The full text of the UE declaration of conformity is available at: www.mikto.eu (search on reference).